

S-1 **(2521) WALKS**

- *Use when there is colored concrete on job (walks, median walks, concrete truck aprons).*
- *Always use SP2018-260 ((3752) MEMBRANE CURING/SEALING COMPOUND FOR COLORED CONCRETE) with this write-up.*

NEW WRITE-UP 01/04/19 ◀DO NOT REMOVE THIS. IT NEEDS TO STAY IN FOR THE CONTRACTORS.

SP2018-188.1

MnDOT 2521 is modified with the following:

S-1.1 MnDOT 2521.3.D.1.b(3) shall be deleted and replaced with the following:

D.1.b(3) Placing, Finishing and Curing Colored Concrete

- (1) Use a curing/sealing compound on approved products list conforming to 3752, “Membrane Curing/Sealing Compound for Colored Concrete.”
- (2) Apply the curing/sealing compound within 30 minutes of concrete placement/form removal or once the bleed water has dissipated, unless the Engineer directs otherwise in accordance with 2521.3.E.1.a, “Membrane Curing Method.”
- (3) Ensure that the curing/sealing compound is applied homogeneously to provide a uniform coverage on all exposed colored concrete surfaces including the edges.
- (4) Apply an additional application of curing sealing compound a minimum of 30 days after placement of the colored concrete.

Cover adjacent finished surfaces to protect from splatters and excess materials during colored concrete installation and curing/sealing.