



CONTINUOUS COUNT LOCATIONS

METRO AREA

- ★ ATR (VOLUME)
- ATR (VOLUME/SPEED/CLASS)
- WIM



0 1 2 4 6 8 Mi.



For information on ATRs and continuous classification contact:
 Mike Merrill
 651-366-3863
michael.merrill@state.mn.us

For information on Weigh-In-Motion stations contact:
 Greg Wentz
 651-366-3865
gregory.wentz@state.mn.us