

## Recommended Spacing for Objects in Signcad

2020

Text Size (IN)	Recommended spacing (IN)
20	12
16	10
15	9
13.333	8
12	7.5
10.667	6
10	6
8	5
6	4
4	3

* for panels with only shield & arrows		
Shield (IN)	Text Size in Shield (IN)	Recommended Spacing (IN)
36	15	9
24	10	6
18	7	4

NOTES: Text size is Primary Designation Text, not ACTION MESSAGE text size  
 Final object spacing must meet at least 50% of text size and should not exceed  
 75% of text size.